

WARB
SPEED

TM

CINEMAWARE

C O R P O R A T I O N

presents

WARP SPEED

by Alien Technologies, Inc.

Copyright © 1988 Cinemaware Corp. All rights reserved.
Warp Speed™ is a trademark of Alien Technologies, Inc.

CONGRATULATIONS!

You now own the most useful and complete cartridge utility ever produced for the Commodore 64 and 128 computers: the Warp Speed™ Fast DOS Cartridge from Cinemaware. It contains the fastest Commodore-compatible DOS ever produced, allowing you to format disks, load, save, verify, and copy files up to ten times faster than before! In addition, Warp Speed includes: a full-featured machine language computer-and-disk-drive monitor/ assembler, with up/down scrolling and an integrated sector editor; an expanded DOS wedge for convenience when using a disk drive; complete support for two or more disk drives, including a 30-second two-drive copier for making convenient backups of your unprotected disks; a reset button; and an "unnew" feature to restore BASIC programs, for recovering control of your computer when you experience a "crash".

All Warp Speed functions work identically on the 64 and 128 in both 40- and 80-column modes, and are fully compatible with most commercial software, including many heavily protected programs that are incompatible with other cartridge utilities. They also work with most compatible disk drives, including the new Commodore 1581 floppy drives and several of the new hard disk drives available, as well as the MSD dual drive popular with many developers.

Whether you are a beginner, a serious hacker, or a professional developer, you will find Warp Speed an indispensable aid which you may never remove from your computer once you have plugged it in!

Fast Load/Save/Verify

, When the Warp Speed cartridge is inserted into the expansion port of your computer, the fast disk access routines are automatically engaged during all disk loads and saves. The routines will work with any application which uses Kernal load and save routines but not the Kernal restore routine (which resets the vectors to their default values). The fast load routines are the most compatible of any comparable cartridge-based loader and work with approximately 99% of all commercially available software. However, the fast-loading DOS can be easily disabled and re-enabled if necessary.

The speed at which files will load depends on how they were originally saved. Files saved with a 1541 disk drive without the aid of Warp Speed are written out in a skew 10 format. This means that after each sector is written to a disk, 9 sectors are skipped before the next sector is used. Warp Speed loads these files as fast as the data goes by the drive head, approximately 500% faster than a 1541 alone. If, however, the files were saved using a 1571 disk drive or with the Warp Speed fast save function, they were written in a skew 6 format, skipping only 5 sectors each time, and can be loaded up to 1,000% faster than a normal Commodore 64. Other fast loaders can only load these files about 300% faster.

Copyright © 1988 Cinemaware Corp. All rights reserved.
Warp Speed™ is a registered trademark of Alien Technologies, Inc.

Most older commercial programs were created with a 1541 disk drive, and should be file copied to new disks using Warp Speed so that the maximum improvement in loading times can be obtained. Warp Speed will load, save and verify at the same speed regardless of the type of disk drive (or mode on a Commodore 128). The scratch and validate commands will work fastest if the drive is a 1571 in double-sided mode.

The DOS Wedge

The DOS wedge consists of a group of commands to take some of the hassle out of disk access. These commands simplify loading and saving files, viewing directories, etc.

Loading files. To load a machine language file, use the percent `<%>` key followed by the file name and `<return>`. This is the same as typing `load "filename".8.1` from BASIC. To load a program to the start of BASIC, use the diagonal slash key followed by the BASIC file to load, then press `<return>`. This is comparable to typing `load "filename".8`. To load and run the first file on the disk, press the Commodore `<C=>` and `<run/stop>` keys at the same time. (This will ALWAYS load the first file on a disk – we have fixed the bug in Commodore's DOS which would occasionally cause the wrong file to load.)

When loading from multiple drive systems, Warp Speed will search both drive 8 and drive 9 looking for the file. If it finds the file, it will change the currently logged drive to the drive on which it found the file.

Saving files. To save a file, type the backarrow `<←>` key followed by the name of the file, then `<return>`. This corresponds to the BASIC command `save "filename".8`. The file will be saved to the currently logged drive unless the drive number is specified in the command.

Verifying files. To fast-verify a file, type an exclamation point `(!)` followed by the name of the file to be verified, then press `<return>`. It is equivalent to the `verify "filename".8.1`.

Listing files and directories. You can list any normal text file to the screen using the ampersand `&>` key followed by the name of the file and `<return>`. There is no equivalent BASIC command to do this, but it is similar to the MS-DOS "TYPE" command. To view the directory of a disk, type a dollar sign `<$>` then `<return>`. The directory will be printed to screen without affecting program memory. In both cases, you can pause the listing and restart it by using the spacebar, or exit at any time using `<run/stop>`.

Setting the currently logged drive. You can manually set drive by using the number sign `<#>` followed by the drive number and `<return>`. The number sign by itself will toggle back and forth between drives 8 and 9.

Accessing the drive command channel. The circumflex `<@>` followed by `<return>` will print the current drive error status to screen. This is the equivalent of doing an `open 15.8.15` from BASIC and reading the error channel. You can also send a command to the drive in this way. See the section on drive commands for more information.

Entering the main menu and machine language monitor. To enter the main menu, use the english pound `<£>` key. To enter the built-in machine language monitor, use the pi `<π>` key.

Utility Commands

Several additional utility commands which start with the up-arrow <↑> key can be used from BASIC. They are also available from the machine language monitor (described later) when preceded by the circumflex <@> character.

The disk menu command, < ↑ > <\$>, will load the directory into the computer's memory and will allow you to scroll up and down through the directory to select a file to load and/or run.

The kill fast-dos command, < ↑ ><k>, disables only the fast loader -- all other functions, including the wedge, will remain active. The enable command, < ↑ ><e>, re-activates the load, save and restore vectors.

The unnew command, < ↑ ><u>, can be used to restore a BASIC program after a new command, or after using the reset button to recover from a crash.

The re-number drive command, < ↑ ><r>, or < ↑ ><r><drive number> can be used to temporarily change the device number of the currently logged drive to another number. If, for example, you had two disk drives, both set as drive 8, you could use the < ↑ ><r> command to change one to drive 9, then power up the second drive and have a powerful two-drive system to work with.

The screen hard-copy command, < ↑ ><h>, will print a copy of the screen contents to a printer connected as device number 4 (text screens only). With the type file <\$> command, you can then print a text file without even loading a word processor! (This feature is also great for printing those readme.doc files that come with many public domain programs.)

Owners of 1571 disk drives will appreciate the set format commands, < ↑ ><s> and < ↑ ><d> for single- and double-sided modes, respectively. These commands will allow you to use a 1571 in single- or double-sided mode regardless of whether you are working with a 64 or a 128. We recommend placing the drives in double-sided mode at all times, especially when scratching a file or validating a disk, as these processes will go much faster when the drives are in double-sided (2 Mhz) mode. A couple of exceptions to this rule: don't place a 1571 in double-sided mode when loading most copy-protected Commodore 64 software, and don't place in them double-sided mode when working with "flippy" disks (different programs on each side of the disk) if you intend to format only one side.

The format commands, both our fast-format and Commodore's own format command, use the drive's current mode to determine whether to format the disk as single- or double-sided. If your drive has trouble reading a single-sided disk when set to double-sided mode, then you should contact Commodore to obtain their upgraded drive ROMs, which are considerably improved over the original ones.

Using the Menu Functions

The english pound key, "£," activates the built-in menu-driven features of Warp Speed. Upon entering the menu system, the Main Menu will appear. There are nine options to select:

1. View Directory
2. Sector Editor
3. File Utilities
4. Single Copier
5. Dual Copier
6. Drive Command
7. Set Drives
8. ML Monitor
9. Quit To BASIC

Select the desired option by moving the highlighted cursor up or down with the cursor key and then press <return>; or you can press the number key to choose the option you want. Two other keys are also active in the menu system: the spacebar can be used to swap source and target drive assignments, and the "Q" key will exit directly back to BASIC.

Here are brief descriptions of the nine menu choices available on the main menu.

1. VIEW DIRECTORY

Shows both the source and target drive directories on the screen. Use the spacebar to pause and restart the directory listing. Press the <run/stop> key once to end the first drive/directory; press <run/stop> a second time to end the directory display. Use <q> to return to the main menu.

2. SECTOR EDITOR

Can be used to edit a data file or a program file directly on a disk without having to first load the file into the computer's memory. Use <q> to return to the main menu. See the section on the Sector Editor for instructions.

3. FILE UTILITIES

Brings up a second menu of choices for file handling. Choices include copying one or more files, scratching one or more files, selecting a file from the disk menu feature, using drive commands, or setting drives.

See the list in the command summary for an explanation of the commands in the sub-menu selections.

4. SINGLE COPIER

Activates a sub-menu for a disk copier which can copy either single or double-sided disks using either one or two disk drives. The utility also verifies both the source and target disks for bad sectors. If you have a disk which this copier will not copy, format a new disk, and use the file copier to copy all the files which are still intact to the new disk. This copier compresses the data during the read process, so many disks which are not completely full can be copied in only one or two passes. Note: double-sided disks can, of course, only be copied on a 1571 disk drive.

5. DUAL COPIER

Activates a sub-menu for a two drive, nibble-type copier which can copy either single or double sided disks (with two 1571 drives) in approximately 30 (single-sided) or 60 (double-sided) seconds. This type of copier, while extremely fast, is not as reliable as the fully verified single copier listed above. It is, however, write verified, so that it will report any errors created during the copy process. If you have difficulty copying a disk with this copier, try switching your source and target drives. If this doesn't work, then you will need to use the single copier with this disk or this hardware.

6. DRIVE COMMAND

Used to display the status of a disk drive, or to send direct access commands to the drive. Press <return> to get the error status; or enter any drive command by pressing the letter of that command and then <return> (see Drive Commands). You can also enter any of the utility commands at the ">" prompt (the commands which begin with an up-arrow). Press <q> to return to the main menu.

7. SET DRIVES

Allows you to set source and target drives for the file copier, disk copiers, and sector editor.

8. ML MONITOR

Enters the machine language monitor. (See Machine Language Monitor later in this manual.) Return to the main menu from the monitor by typing the "XM" command.

9. QUIT TO BASIC

Exits the menu system.

Drive Commands

Drive commands are commands that may be used directly from the Drive Command selection in the main menu, or (when prefixed with a circumflex <@>) from the DOS wedge or machine language monitor. These commands are detailed in the manuals that come with your disk drive. A few of the more useful ones are: <@f>, which does a fully-verified fast format; <@uj>, which resets a disk drive as though it had just been turned on; <@v>, which validates a disk to eliminate bad "PRG" files and clean up the block availability map (BAM) on heavily used disks; and <@s0:><filename>, which will scratch (delete) a file from the disk.

Perhaps the most powerful features of the Warp Speed cartridge are the sector editor and machine language drive monitor. They have been integrated together to create a very powerful program creation, de-bugging and editing tool.

Sector Editor

To enter the sector editor from BASIC, choose 2. SECTOR EDITOR from the main menu. Entering the sector editor in this way will clear an editing buffer from \$7E00 to \$7EFF and set the default track and sector to the start of the directory (usually at track 18 sector 1). From within the machine language monitor, you can enter the sector editor with the <xs> command. Entering this way will not clear the buffer or change the current rack and sector settings, so you can go back and forth between the editor and the monitor to read a file a sector at a time, make any changes you need, and then write the sector back out to disk, without loading the whole file into memory first.

To read a sector, type <r><track><sector> (where the track and sector are in hexadecimal), or just <r> if the default values are o.k. The desired track and sector will be read in and transferred to the editing buffer at \$7E00 in the computer. To write the sector back to the disk, use <w>.

To edit a sector, move the cursor to the desired position with the cursor keys, then enter the new value in hexadecimal. Because of the size of the screen, only half of a sector will be visible at a time. To see the other half, simply move the cursor off the top or the bottom of the data and the other half scroll on . If you are making changes to text, you can simply type in the desired letters by pressing <t> to enter text mode. When you are through typing text, use <run/stop> to exit text mode.

Several keys allow you to move to a different sector on a disk <+> will advance you to the next sector. <-> will move you back one sector. <shift><+> will advance you one track. <shift><-> will move you back one track. The <n> key will allow you to go to the "next" track and sector in a file (as pointed to by the first two bytes in the sector). The <j> key will "jump" to the track and sector pointed to by the bytes currently under the cursor. This can be used by the directory entry of the file to move to the start of the file, so you can edit a complete file without ever entering a track or sector manually!

At any time, if you wish to enter the machine language monitor to edit the data, use the <m> command. Remember to exit back to the sector editor with the <xs> command so your changes won't be erased from the buffer.

If you have a Commodore printer attached as device 4, you can print out the entire sector contents with the <p> command. This is not merely a screen dump, as both halves of the sector are printed together. If you are in the second half of the sector data, pressing <clr/home> once will move you to the top of the screen editing area. Pressing <clr/home> a second time will move the cursor to the beginning of the sector data. Pressing <shift><clr/home> will erase the buffer (fill it with zeros) from the cursor position forward to the end of the sector. Pressing <q> will exit the sector editor. The <run/stop> <restore> combination will always bring you back to BASIC from sector editor (without crashing the machine).

One very powerful (but somewhat dangerous) feature of this sector editor is the use of the source and target drives. This means you can read a sector from one drive, make any changes to it you like, then write it out to a different disk in a second drive. **BE CAREFUL NOT TO DO THIS ACCIDENTALLY!!!** You must set your source and target drives from the main menu before entering the sector editor -- there was no room in our ROM to make this command available from within the sector editor itself. If you find that you do not have the target drive set correctly, you can switch source and target drives by pressing the spacebar. Source and target assignments will then be swapped. Please be careful not to swap them accidentally as well! A write-protect tab can save many headaches by protecting you from such mistakes.

Machine Language Monitor

The machine language monitor is one of the most advanced monitors ever produced for the Commodore 64 and 128. It was designed to be flexible and accept the syntax of most other previously available monitors; for example, you can separate most parameters with spaces, commas, shifted spaces or sometimes no spaces at all.

To disassemble a file, type `<d>` followed by addresses to start and end disassembly at; for example `D 1000 1050` to disassemble \$1000 to \$1050. You can pause and resume the disassembly at any time using the spacebar, or stop using `<run/stop>`. A `<d>` without an ending address will disassemble continuously to the end of the memory. A `<d>` by itself will continue a disassembly from the last address displayed for about a half of screen and then stop again. You can also continue a disassembly (or other memory display) by using the cursor keys to scroll up or down. The `<m>` command (hexadecimal memory dump) and the `<i>` command (interrogate memory in ASCII) work similarly.

To compare the areas of memory, use the `<c>` command followed by the start and ending address of the first block of memory followed by the start address of the second block to compare to, as in `C 8000 9FFF A000` to compare the block at \$8000 to \$9FFF to the block at \$A000 to \$BFFF. Any addresses in the first block which differ from the corresponding addresses in the second block will be printed to the screen. To fill an area of memory with a constant value, use the `<f>` command followed by starting and ending addresses and the value to fill the memory block with.

The `<←>` key followed by a value will set the configuration (bank select) register to the new value. This is location \$01 in a Commodore 64 and \$FF00 in a Commodore 128 in 128 mode. For example, `←34` on a C64 will allow you to peek under the BASIC and Kernal ROMs, and work with the RAM under the I/O block at \$D000. Using `←00` or `←01` in 128 mode will allow you to do the same thing on a C128 for RAM bank 0 and 1, respectively.

The `<r>` command will display the current processor registers and configuration register values. These are the values which the processor will use if you issue `<g>` command to go (execute) a routine, as in `G FCE2` to reset a Commodore 64. If you wish the routine being called to return to the monitor on completion, then end it in a BRK instruction. An RTS instruction would return you to BASIC.

You can hunt for a sequence of bytes in memory with the `<h>` command, as in `H E000 FFFF 8D 00 DD` which will hunt through the Kernal ROMs for all occurrences of the sequence \$8D \$00 \$DD. You can move a block of code from one memory location to another using the transfer `<t>` command, as in `T 1000 1FFF 1002` to move the code which presently sits at \$1000 to \$1FFF to the new location of \$1002 to \$2001. Note that you can move blocks up or down in memory over their current locations without worry -- `our` move command will not turn into an accidental fill command! Two additional transfer commands, `<td>` and `<tc>` will transfer blocks of memory to and from disk drive memory, respectively.

To output all screen information to a printer attached as device number 4, use the <p> command to toggle the printer output on and off. While output is redirected to the printer, no screen printing will occur.

You can also assemble a program with the <a> command, as in A 1000LDA#\$01 which will assemble the instruction LDA #\$01 to \$1000. Spaces here are optional.

The <o> I/O command can be used to switch from programming in computer RAM to disk drive RAM. Use Q 08 to move to drive 8 RAM, or <o> by itself to return to the computer. All of the monitor commands are available when programming in the disk drive except <I> and <←>.

The <\$> command will list the directory of the currently logged drive to the screen. <@#> can be used to toggle between two drives (see the DOS Wedge). All DOS wedge commands are available, as are all utility commands provided you precede them with a circumflex <@> as in @↑R 0A to renumber the currently logged drive to drive 10 (see Utility Commands).

The load, save and verify commands (<l>, <s> & <v>) all work similarly. The syntax is <l> (or <v>) then the filename followed by an optional drive number and an optional relocated load address. For example L "myprogram" I234 will load a file from the currently logged drive (or a second drive if the first returns "file not found") and relocate it to the address \$I234. Note that you do not have to specify a load address if the default one saved with the file will do. Similarly, S"yourprogram" 08 I234 5678 9AB would be used to save a program from the range of \$I234 to \$5678, inclusive, to a disk on drive 8 and give it the new default load address of \$9ABC. As in the load command you do not have to specify a disk drive number, but if you have more than one drive it is a good idea. If you do not specify the third address, then the default load address will be the same address as the file is being saved from.

Finally, there are five ways to exit the monitor! The <q> command will return to BASIC, and restore the BREAK vector back to its normal value (pointing to BASIC Warm Start on a C64 and Commodore's monitor on a C128 in 128 mode). The <x> instruction will also exit to BASIC, but the BREAK vector will remain set to re-enter the cartridge monitor. <xs> will exit to the sector editor, <xm> will exit to the cartridge main menu, and <xc> will cause a cold start of BASIC (clearing the BREAK vector in the process).

So, there you have it. We hope you enjoy working with your new accelerator cartridge! We have spent many hours designing and programming it to be the finest utility available for a Commodore 64 or Commodore 128. We have taken 32K of machine language code, and re-written it over and over until we could fit it inside a 16K ROM (to keep your cost down). We ended up with zero bytes left over, not even enough room to credit the programmers! The Alien Technologists who devoted over two man-years to create this product are Marty Franz, Joe Peter and Harald Seeley. Many thanks are also do to Bob and Phyllis Jacob as well as John Cutter for their faith in our efforts.

FILE UTILITIES SUMMARY

move cursor	<crsr>
toggle highlighted selection	<spacebar>
toggle selection and move cursor	<return>
toggle all files	<a>
toggle remaining files (below cursor)	<d>
move cursor to top of directory	<clr/home>
new disk directory	<↑>
start function on selected files	<s>

SECTOR EDITOR SUMMARY

read sector from source drive	<f><track><sector>
write sector to target drive	<w><track><sector>
move cursor in sector	<crsr>
move cursor to start of sector	<clr/home>
go forward one sector	<+>
go back one sector	<->
go forward one track	<shift><+> (both keys simultaneously)
go back one track	<shift><-> (both keys simultaneously)
jump to track/sector at cursor	<⌘>
next sector in file	<⌘>
enter text mode	<⌘>
exit text mode	<run/stop>
enter monitor	<⌘>
print entire sector	<⌘>
clear sector from cursor to end	<shift><clr/home> (both keys simultaneously)
exit sector editor	<⌘>
swap source and target drives	<spacebar>

Monitor Command Summary

All items in parentheses are required. All items in <> are optional.

assemble command	A (address)(mnemonic)<operand>
compare memory	C (start address) (end address) (compare address)
disassemble	D <start address> <end address>
fill memory	F (start address) (end address) (value)
go (execute)	G (address)
hunt (find) a byte sequence	H (start address) (end address) (sequence)
interrogate memory in ascii	I <start address> <end address>
load file	L (filename) <drive #> <address>
memory dump (hexadecimal)	M <start address> <end address>
I/O	O <drive #>
toggle printer	P
quit	Q
display register	R
save file	S (filename) <drive #> (start address) (end address)<load address>transfer block
	T <D,C> (start address) (end address) (new address)
verify file	V (filename) <drive #> <address>
exit	X <S,M,C>
set configuration register	← (val)
directory	\$
use drive command	@ (drive command) (see Drive Commands)

DOS WEDGE SUMMARY

load file	</><filename>
load binary file	<%><filename>
load and run first file on disk	<c=><run/stop> (both keys simultaneously)
save file	<<-><filename>
verify file	< ><filename>
type file	<&><filename>
view directory	<\$>
set drive number	<#><drive #>
use drive command channel	<@><command> (see Drive Commands)
enter main menu	<f>
enter machine language monitor	< >

UTILITY COMMAND SUMMARY

display directory in menu format	<↑><\$>
disable ("kill") fast-access routines	<↑><k>
enable fast-access routines	<↑><e>
restore ("un-new") BASIC program	<↑><u>
renumber currently logged disk drive	<↑>< ><drive #>
print ("hard-copy") current screen	<↑><h>
single-sided mode (1571 drives only)	<↑><s>
double-sided mode (1571 drives only)	<↑><d>

Congratulations! You are now the proud owner of another program from Cinemaware's bestselling line of computer software!

Because we really want to know about the people buying Cinemaware software, we *strongly encourage* you to fill out and return the attached product registration card.

When you complete and return this card, you help us get a profile of the people who buy our software. By learning more about your interests and software buying habits, we can more effectively serve your needs when producing future Cinemaware software products.

Make certain when you fill out the registration card that you accurately record your complete name and address, including the Zip code. That way we can send you information on future Cinemaware products as they are published.

So send in those cards! We want to know about you!



**Cinemaware Corp.
4165 Thousand Oaks Blvd.
Westlake Village, CA 91362**

LIMITED WARRANTY

Cinemaware Corp. warrants to the *original purchaser* of this computer software product that the recording medium on which the software program is recorded, and the software program itself, will be free from defects in material and workmanship for 90 days from the date of purchase. If during this period a defect should occur, all media may be returned to Cinemaware along with proof of date of purchase and a brief description of the defect (to ensure proper handling of the problem). Include your return mailing address, and if possible a daytime phone number. The media will be repaired or replaced (Cinemaware's option) without charge to the user, provided that the returned media has not been subjected to misuse or damage by the user.

If the media has been subject to misuse or damage, or if at any time after the initial 90 day period the media becomes defective, all media may be returned to Cinemaware for repair or replacement with a \$10 service charge (which includes shipping and handling). A brief description of the problem should be included with the returned media.

Return *all* media to Cinemaware, 4165 Thousand Oaks Blvd., Westlake Village, CA 91362.

Cinemaware Corp. does not warrant that the programs will meet the purchaser's specific requirements. Any statements concerning the utility of the programs are not to be construed as express or implied warranties. This warranty is in lieu of all other warranties, whether oral or written, express or implied. Any implied warranties, including implied warranties of merchantability and fitness for a particular purpose, are excluded. In no event will Cinemaware Corp. be liable for incidental or consequential damages of any kind in connection with the software products.

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

COPYRIGHT NOTICE:

Copyright © 1988 Cinemaware Corporation. All rights reserved.

The owner of this software product shall be entitled to use the product for his or her personal use, but shall *not* be entitled to sell or transfer reproductions of the software, manual or related materials to other parties in any way, nor to rent or lease the product to others without the prior written permission of Cinemaware Corp.

Any person or persons reproducing any portion of this program, in any media, for any reason, shall be guilty of *copyright violation*, and shall be subject to civil liability at the discretion of the copyright holder. Unauthorized copying of any Cinemaware product is a violation of Federal law. Violation may carry a fine of up to \$50,000, or imprisonment, or both.

CINEMWARE PRODUCT REGISTRATION

Thank you for purchasing a Cinemaware product! Please complete and return this registration card so that we may have a record of your purchase, and also keep you informed of new releases from Cinemaware.

Name Mr. Ms. _____ Phone _____

Address _____

City _____ State _____ Zip _____ Country _____

Product purchased _____ Date purchased ____/____/____

Store where purchased: _____ Price paid: _____

My computer is: Apple IIGS Macintosh Atari ST Amiga

Com. 64/128 IBM PC/XT/AT other IBM compatible (brand: _____)

If IBM PC/XT/AT or compatible, what type of graphics card is installed in your computer?

monochrome CGA MCGA. EGA VGA

From what type of store was this game purchased?

Software store Computer store Electronics store Toy store

Dept. store Discount store Mail order Bookstore Other

How long have you owned your computer?

under 3 mo. 3-6 mo. 6-12 mo. 1-2 yrs. over 2 yrs.

Primary user's age: under 10 yrs. 10-17 yrs. 18-30 yrs. 31-50 yrs. over 50

Number of other computer games owned:

0-2 3-5 6-10 11-20 over 20

Number of other Cinemaware games owned:

0 1 2 3 over 3

Favorite computer game (any publisher): _____

Favorite Cinemaware game: _____

What computer magazines do you read? _____

Comments: _____

